





100% of Actual Size  
Screen Print

POSITION A




100% of Actual Size  
Pad Print

POSITION D




POSITION E




Please note when pen is printed in position D,  
print is not visible when in the notebook holder.

100% of Actual Size  
Direct Digital

POSITION D



POSITION E



Please note when pen is printed in position D,  
print is not visible when in the notebook holder.

100% of Actual Size  
Pad Print



Branding area can be moved anywhere within the red line.


100% of Actual Size  
Screen Print (one colour)




100% of Actual Size  
Direct Digital

120mm

190mm



100% of Actual Size  
BACK Pad Print



Branding area can be moved **anywhere within the red line.**

100% of Actual Size  
BACK Screen Print (one colour)

